

6A815E1 / 6A815EP1

User's Manual Version 2.0

The information presented in this publication has been made carefully for reliability; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.

Socket370 is a trademark of Intel Corporation

AWARD is a registered trademark of Phoenix Software Inc.

MS-DOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

Trademarks and/or registered trademarks are the properties of their respective owners.

Table of Contents

Introduction

1. Motherboard Description

1.1 Features	
1.1.1 Hardware	1-2
1.1.2 Software	1-5
1.1.3 Attachments	1-5
1.2 Motherboard Installation	
1.2.1 Motherboard Map	1-6
1.2.2 Motherboard Layout	1-7
1.3 Motherboard Connectors	
1.3.1 Front Panel Connector(J7)	1-9
1.3.2 Floppy Disk Connector(FDD1)	1-10
1.3.3 Hard Disk Connectors(IDE1/IDE2)	1-10
1.3.4 ATX 20-pin Power Connector(PW1)	1-11
1.3.5 Infrared Connector	1-11
1.4 Back Panel Connectors	
1.4.1 PS/2 Mouse/Keyboard CONN.	1-12
1.4.2 USB Connectors	1-12
1.4.3 VGA Interface Connector	1-12
1.5 Serial and Parallel Interface ports	1-14
1.6 CPU Installation	
1.6.1 CPU Installation Product(Socket 370)	1-16
1.7 Jumper Setting	
1.7.1 CPU Fan Connectors(FAN1/2/3)	1-17
1.7.2 BIOS Flash(JP4)	1-18
1.7.3 Keyboard wake up Setting(JP7)	1-18
1.7.4 CMOS Function Setting(JP6)	1-18
1.7.5 CNR Card Setting(J8)	1-19
1.7.6 STR LED(LED1)	1-19
1.7.7 IrDA Connector(IR)	1-19

Table of Contents

1.8 DRAM Installation	
1.8.1 DIMM	1-20
1.8.2 How to install a DIMM Module	1-20
1.9 Audio Subsystem	
1.9.1 CD-Audio-IN Connector(CN1)	1-21

2. BIOS Setup

2.1 Main Menu	2-4
2.2 Standard CMOS Features	2-7
2.3 Advanced BIOS Features	2-10
2.4 Advanced Chipset Features	2-14
2.5 Integrated Peripherals	2-17
2.6 Power Management Setup	2-23
2.7 PnP/PCI Configurations	2-27
2.8 PC Health Status	2-31
2.9 Frequency/Voltage Control	2-33
2.10 Load Fail-Safe Defaults	2-34
2.11 Load Optimized Defaults	2-35
2.12 Set Supervisor/user Password	2-36
2.13 Save & Exit Setup	2-38
2.14 Exit Without Saving	2-39

3. Driver Installation

3.1 Auto-run Menu	3-1
3.2 Installing Intel INF Driver	3-2
3.3 Installing Ultra ATA Driver	3-3
3.4 Installing Hardware Monitoring Utility	3-4
3.5 Installing VGA Driver	3-5
3.6 Installing Sound Driver	3-7
3.7 Installing Easy Over Clock Driver	3-8